


# Super Series Pump XHDH500SS

**15 litres/min 300 bar**



## LUBRICATION OF THE PUMP

We recommend:

### VTUF PL500 – Pressure Lube Pump Oil – Fill Pump To Halfway

You should change the oil after the first 50 hours of use, and after each subsequent 500 hours of operation.